

PSA Film Installation



RECOMMENDED TOOLS:

Utility knife, putty knife, 4" smoothing tool, ceramic edge trimmer (optional)

RECOMMENDED SUPPLIES:

Putty, sanding block, rags

- 1 Unroll film and lay flat for 24 hours prior to installation.
- 2 Clean and prep cabinets. Surface imperfections will telegraph through the film, so fill holes, and sand defects smooth. If the surfaces to be refinished are greasy or oily, wipe them down with a cleaner/degreaser prior to installing the film.
- 3 Rough cut size(s) and dry fit each piece of film, prior to removing its backer.
- 4 Wipe down the surface with a damp rag. This moisture will allow you to remove or adjust the film location for a short time after application.
- 5 Remove 3-6" of the backer at a time while simultaneously applying to the surface.
- 6 Use a squeegee to push out air pockets or bubbles. If you put the film in the wrong place, reposition immediately because the adhesive is aggressive and will become more difficult to remove as time passes.
- 7 Trim excess film with a utility knife and/or a ceramic edge trimmer (slow and easy).